

3 Phase Diagram

Instructions

1. Connect Alligator lead into IEC Socket of the TnT Tester.
2. Connect metal pin or nail in between alligator clip (Image 1)
3. Connect 3 Phase Adaptor or Multi Adaptor into appliance socket of the TnT Tester.
4. Connect Male pin of the extension lead into the 3 Phase Adaptor plug (20A)
5. Insert metal pin/nail into the Earth hole (E) on the female pin (of the 3 Phase extension lead).
6. Select F3 Extension Lead Test from the main menu of the TnT Tester to test the lead.

